


CUBE2, CUBE4


PENDANT CABLE INSTALLATION INSTRUCTIONS



Specifications: CUBE2


Width: 2.5 (64)
Depth: 4 (101)

All dimensions are in inches (millimeters).




Specifications: CUBE4

Width: 4 (101)
Depth: 4 (101)




Cable




1

Install canopy bracket(A) on to j-box and Run power cord(B) through Power feed canopy(C) and secure the power cord inside the canopy. Connect the power cord to the ceiling power feed from j-box. Place canopy in position on Threaded stud and secure with cable mounting nut(G).



2

Install Grip lock(D) to each end of housing.



3

Run Aircraft cable(E) through Grip lock installed on fixture and adjust height by pushing Grip lock.

UTOPIA
LIGHTING

310-327-7711
utopialightingus.com
info@utopialightingus.com

Contractor is responsible for adequately reinforcing ceilings to support luminaire weight. Utopia Lighting accepts no responsibility for inadequately reinforced ceilings. The information contained in this drawing is the sole property of Utopia Lighting. Any reproduction in part or whole is prohibited and warranty voided.

WARNING:



RISK OF FIRE AND ELECTRICAL SHOCK. FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY IN ACCORDANCE WITH NATIONAL, LOCAL BUILDING AND ELECTRICAL CODES. DISCONNECT POWER AT ELECTRICAL PANEL BEFORE SERVICING.

CUBE2, CUBE4


PENDANT CABLE INSTALLATION INSTRUCTIONS

CONTINUOUS ROW

TOOL(S) NEEDED:

Option 1) Cordless drill and an elbow or L-shape adapter with Philips Insert Bit extension.

Option 2) Flexible Screwdriver with Philips Insert Bit.



- 1) Make wiring connection from each fixture power supply wires together.
- 2) Align fixtures and screw together with 4 screws(H).




CUBE2, CUBE4

PENDANT CABLE INSTALLATION INSTRUCTIONS


CUBE2

INDIVIDUAL




CUBE4

INDIVIDUAL



CONTINUOUS



CONTINUOUS

