

**Powertrain Plus Service Protection covers the most essential (and often the most expensive) parts of your vehicle to repair. It features a \$0 deductible when repairs are completed by your selling dealer (or \$100 per claim elsewhere).**



This is a general outline of coverage for marketing purposes only and does not constitute your contract. Actual terms and conditions may vary by state. See your contract for complete provisions, exclusions and Limits of Liability.



**Ascent**  
ADMINISTRATION SERVICES

ADMINISTERED BY:  
**ASCENT ADMINISTRATION SERVICES, LLC.**

 **TOLL-FREE 866-660-7003**



## **POWERTRAIN PLUS**

### **VEHICLE SERVICE PROTECTION**



Coverage terms from 1 Month / 1,000 Miles  
up to 60 Months / 60,000 Miles

Lifetime Coverage Also Available


\$100 Disappearing Deductible



# Big Repairs Covered. Big Worries Gone.

## Powertrain Plus Vehicle Service Protection

Coverage terms range from 1 Month / 1,000 Miles  
up to 36 Months / 36,000 Miles.



**C** **ZERO**  
DEDUCTIBLE  
when  
repaired at  
the selling  
dealer!

### WHAT'S COVERED

(or only \$100 per claim if  
repairs are done elsewhere)

**ENGINE:** Cylinder block and all internal parts; cylinder head assemblies; timing case/cover; timing chain, timing belt, tensioners, gears, sprockets, and guides; serpentine belt with starter ring gear; core plugs; valve covers; oil pan; factory-installed turbocharger/supercharger including internal parts; EGR valve; crank sensor; and cam sensor.

**ENGINE COOLING SYSTEM:** Water pump and housing; fan clutch; thermostat; radiator; heater core; and recovery tank.

**AUTOMATIC TRANSMISSION:** Transmission case and all internal parts; bell housing; transmission pan; torque converter; pressure sensors; PRNDL position switch; transmission control module; valve body; mechatronics unit; conductor plate; servo assemblies; transmission cooler; reprogramming; and transmission case bell housing (only if damaged by a covered component internal to the transmission/transfer case housing).

**MANUAL TRANSMISSION:** Main shaft; countershafts; all gears; chain; input shaft; hub assemblies; synchronizers; shift rails; shift forks; internal transmission bearings; transmission case (only if damaged by a covered component internal to the transmission/transfer case housing); and lubricated parts contained within the transmission case housing. Manual transmission clutch parts are not covered at any time.

**FLUIDS:** Fluids are covered only when required in conjunction with a covered component.

**SEALS & GASKETS:** Seals and gaskets are covered for leakage failures as they relate to any listed covered component for vehicles with less than 125,000 miles at the time of claim. Seepage is not covered and cannot be claimed. For vehicles with over 125,000 miles at the time of claim, seals and gaskets are covered only when required in conjunction with a covered component. Cylinder head gaskets are covered only for combustion and coolant leaks. Intake manifold gaskets are covered only for coolant leaks.

**FRONT-WHEEL DRIVE:** Transaxle case and all internal parts; axle shaft assemblies; constant velocity joints and boots; differential cover; transaxle speed sensors; transaxle solenoid assembly; transaxle electronic controller; and wheel bearings/hub assemblies. Transaxle case only if damaged by a covered component internal to the transaxle case housing.

**ALL-WHEEL DRIVE:** Power transfer unit and all internal parts; viscous coupler; axle housing and all internal parts; constant velocity joints and boots; drive shaft and axle shaft assemblies; differential carrier assembly and all internal parts; clutch; vacuum motor; torque tube; pinion spacer and shim; and wheel bearings/hub assemblies. Power transfer unit case only if damaged by a covered component internal to the power transfer unit housing.

**REAR-WHEEL DRIVE:** Rear axle housing and all internal parts; axle shafts; axle shaft bearings; drive shaft assemblies; drive shaft center bearings; universal joints and yokes; wheel bearings/hub assemblies; and rear axle housing (only if damaged by a covered component internal to the rear axle housing).

**FOUR-WHEEL DRIVE (4x4):** Transfer case and all internal parts; transfer case control module and shift mode motor assembly; axle housing and all internal parts; axle shafts; axle shaft bearings; drive shafts assemblies (front and rear); drive shaft center bearings; universal joints; 4x4 hubs; yokes; wheel bearings/hub assemblies; and disconnect housing assembly. Transfer case housing only if damaged by a covered component internal to the transfer case housing.

### ENHANCED BENEFITS OPTION

Available with surcharge, this option expands the Limit of Liability (maximum payable for all claims over the life of the service contract) to \$9,000.

Expand  
Your  
Coverage!

