RHS

Roof Heating Systems

Owners Manual

Read this owner's manual thoroughly before operating the product and keep it handy for reference at all times.



SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

- Never pull, drag, or lift the heated mat by the power cord.
- Never plug to power RHS heated mat when product is rolled.
- Never overlap mats, if more than one.
- Do not cover the mat when working or place any objects on top of it.
- Connect RHS heated mats only on properly grounded circuits.
- Never connect your RHS heated mats to a voltage higher than what is listed on the label attached to the product.
- Do not use indoors.
- Do not puncture or cut the product.
- Never use ungrounded, worn, or damaged extension cords.
- Do not use for pets. Too Hot.
- Use only for melting snow and prevent ice formation (ice dams).
- The RHS heated mat is not intended for use by young children.
- Connect to a properly rated, protected, and sized power circuit to avoid electrical overload.
- Do not under any circumstances, cut or remove the third (ground) prong from the power cord.
- Adhere to all industry recommended safety procedures including the use of longsleeved gloves and safety glasses.
- Use care when unpacking and installing. The grommets of the product may be sharp.
- Disconnect the power cord or circuit breaker before installing or servicing the appliance.
- Keep packaging materials out of the reach of children. These materials can pose a suffocation risk to children.
- Warning: improper installation and usage may result in injury or death.
- **Do not use on decks. Contact decking manufacturer for restrictions.**

OPERATIONS

- Use RHS heated mat only for its intended purpose.
- Never attempt to operate this product if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug.
- If water enters the product, turn off the power at the main circuit, then unplug the product and call for service.
- Unplug the product when unused for long periods.
- Unplug RHS heat mat if temperatures reach above 40° degrees Fahrenheit.
- Unplug the product before cleaning.

GENERAL INSTALLATION GUIDELINES

STEP 1

- All of RHS heated mats are to be installed on surfaces that are free from debris, such as small rocks, gravel or other objects that can damage the RHS heated mats. Always clean the area prior installation.
- Commercial RHS snow melting mats such as the diamond or herringbone texture have a non-slip surface. For correct use of the snow melting mat, use texture side up for best performance. Valley heaters and sandpaper design have a nonslip surface on both sides.
- Install mat in the desired location.
- Make sure RHS heated mat is secure in place and cord is in a secure position free of tripping risks.

STEP 2

- Plug RHS Heated mat 3-pronged, grounded plug into a proper electric outlet.
- Make sure RHS heated mat is working properly.

OBSERVATION

If plugging more than one heat mat together, make sure that the overall amperage will not exceed 15 amps. To prevent circuit overload and any malfunctions.

RHS
Roof Heating Systems

Roof Heating Systems
192 Anawan Street, Unit 101
Fall River, MA 02721
(774) 678 - 4039