


Mini-Studio - How to Digitize Your Product


Step 1

Place the textile flat on a white surface making sure the right side is facing upwards.




Step 2

Place the Mini-Studio on top, ensuring the **long** side of the Mini-Studio is parallel to the **weft** of the textile.




Step 3

Place the Softbox on top of the Mini-Studio, passing the wires through the top opening. Plug the 2 wires following the **Plug and Play** instructions. You are now ready to begin digitization.



Limitations of the Tengiva Mini-Studio - What it cannot digitize

The following represent textiles that the Tengiva Mini-Studio cannot digitize.



Transparent or/and textiles with holes



Lace




Denim

Avoid working on 2 screens at the same time - it may affect the processing speed and accuracy of the camera.

Mini-Studio - How to Digitize Your Product


Step 4

Sign into www.tngv.io/vrstex using your account information.




Step 5

In the left menu bar, select **Manage**, than Digitization request.




Step 6

At the top of the page, select the tab labelled **Manual DIY**.




Step 7

Click **View** next to the product you wish to digitize.



Step 8


A new tab will open. Click **Continue** next to the product you wish to digitize.



Mini-Studio - How to Digitize Your Product


Step 9

You will arrive at the product configuration page where you will need to fill out certain information on the textile (greige information, color ID, LAB, quality, etc).




Step 10

At the bottom of the page, you will see FRONT FABRIC IMAGE. Select **Capture a photo**, found on the right.




Step 11

The following display will appear on your screen. Select which preset suits the textile you are digitizing from the options A), B) or C).



Step 12

The following display will appear on your screen. Make sure the camera **16MP USB Camera** is selected. Select **Allow while visiting site**.



Mini-Studio - How to Digitize Your Product


Step 13

The following display will appear on your screen. Please read the displayed steps. Once you are ready, press **Take Photo**.

Specification for Preset B




Getting the right picture with present B may be difficult. We encourage you to use the auto-focus, auto-brightness and color correction toggles to achieve better results.




Step 14

Once you are pleased with the photo results, select **Confirm and upload**.




Step 15

Flip the textile swatch around to digitize the back side. Select **Capture a photo** found next to BACK FABRIC IMAGE.




Step 16

The following display will appear on your screen. Select which type of textile you are digitizing from the options D), E) or F).



Step 17


The following display will appear on your screen. Please read the displayed steps in order to properly use the present selected. Once you are ready, press **Take Photo**.



Mini-Studio - How to Digitize Your Product


Step 18

Once you are please with the photo results, select **Confirm and upload**.



Step 19

Now that the photos have been taken, select **Save**.



Step 20

Scroll to the top and **Mark Complete**.

